

Page number format: s-p [pdf]
 s-p = section-page of hardcopy
 [pdf] = page of PDF file

BEFORE USING i [3]
 CONTENTS v [7]
 1 INSTALLATION AND CONNECTION ... 1-1 [13]
 2 NAMES AND FUNCTIONS OF PARTS .. 2-1 [21]
 3 MENU 3-1 [33]
 4 BASIC OPERATIONS 4-1 [45]
 5 COMMUNICATING AIDS 5-1 [57]
 6 REJECTING INTERFERENCE 6-1 [87]
 7 SCOPE FUNCTIONS 7-1 [97]
 8 TRANSMIT FUNCTIONS 8-1 [105]
 9 MEMORY CHANNELS 9-1 [113]
 10 SCAN 10-1 [119]
 11 USB/FILE MANAGEMENT 11-1 [123]
 12 VOICE MESSAGE/AUDIO FILE 12-1 [129]
 13 VOICE GUIDANCE 13-1 [135]
 14 CLOCK DISPLAY/TIMER 14-1 [147]
 15 NETWORK/KNS OPERATION 15-1 [153]
 16 OTHER FUNCTIONS 16-1 [159]
 17 MAINTENANCE AND ADJUSTMENT .. 17-1 [177]
 18 TROUBLESHOOTING 18-1 [181]
 19 OTHERS 19-1 [193]

- A -

AF Gain Adjustment 4-2 [46]
 AGC 5-2 [58]
 AGC Time Constant (F/M/S) 5-3 [59]
 AGC Time Constant Presets 5-3 [59]
 AGC OFF 5-3 [59]
 AGC Quick Recovery 5-3 [59]
 Antenna Install & Connection 1-1 [13]
 Antenna 1/2 Selection 4-10 [54]
 Antenna Tuner (External AT-300 . 4-12 [56]
 Antenna Tuner (Internal) 4-11 [55]
 Matching Antenna Impedance .. 4-11 [55]
 Tuner ON/OFF For Each Band .. 4-12 [56]
 RX Antenna Tuner ON/OFF 4-12 [56]
 Preset Frequency Categories . 4-12 [56]
 Hold Xmit at End of Tuning .. 4-12 [56]
 Antenna Output for External
 Receivers 16-16 [174]
 APO (Automatic Power Off) 14-6 [152]
 Attenuator 6-1 [87]
 Audio Input/Output Configuration 16-7 [165]
 USB-B Connector 16-7 [165]
 ACC 2 Connector 16-7 [165]
 TX Monitor Level for External
 Audio Output 16-7 [165]
 Mixing for External Audio
 Output 16-7 [165]

Audio Peak Filter in CW Mode 6-5 [91]
 Audio Peak Filter ON/OFF 6-5 [91]
 Passband Width Selection 6-5 [91]
 Passband Shift Selection 6-5 [91]
 Audio Peak Filter Gain 6-6 [92]
 Audio Peak Filter in FSK Mode ... 6-6 [92]
 Audio Scope 7-8 [104]
 Displaying the Audio Scope ... 7-8 [104]
 Spectrum Scope Attenuator 7-8 [104]
 Display Frequency Span of
 Spectrum Scope 7-8 [104]
 Oscilloscope Level 7-8 [104]
 Oscilloscope Sweep Time 7-8 [104]
 Pausing the Audio Scope 7-8 [104]
 Audio Transmission 4-8 [52]
 Auto Mode 4-4 [48]
 Auto Mode ON/OFF 4-4 [48]
 Mode Frequency Ranges 4-5 [49]
 Auxiliary Support Legs 1-1 [13]

- B -

Bandscope (all Display Modes) ... 7-1 [97]
 Displaying the Bandscope 7-1 [97]
 Bandscope Display Type
 (Spectrum and/or Waterfall) 7-1 [97]
 Display Mode (Auto Scroll,
 Fixed, or Center) 7-3 [99]
 TX/RX Frequency Markers 7-6 [102]
 Registered Frequency Markers .. 7-6 [102]
 Reference Level 7-2 [98]
 Bandscope Attenuator 7-2 [98]
 Displaying Maximum Value in
 the Waveform 7-7 [103]
 Averaging Spectrum Scope
 Waveform 7-7 [103]
 Pausing Waveform Display 7-7 [103]
 Tuning Assist Line (SSB Only) 7-5 [101]
 Touchscreen Tuning 7-6 [102]
 TX Signal Waveform Display ... 7-7 [103]
 Bandscope Spurious Signals . 18-12 [192]
 Bandscope (Auto Scroll Mode only)
 TX/RX Marker Shift 7-3 [99]
 Bandscope (Auto Scroll & Center Mode)
 Display Frequency Span 7-3 [99]
 Expand Frequency Range 7-4 [100]
 Bandscope (Center Mode only)
 Relative or Absolute Frequency
 Grid Display 7-5 [101]
 Bandscope (Fixed Mode only)
 Scope Range of Each Band 7-4 [100]
 TX/RX Marker Centering 7-5 [101]
 TX/RX Marker Out of Range
 Indicator 7-5 [101]

Bandscope Waterfall
 Speed of Waterfall Drop 7-2 [98]
 Gradation of the Waterfall ... 7-5 [101]
 Waterfall Display during Tuning
 (Center Mode only) 7-2 [98]
 Bandscope Reduced Display 7-2 [98]
 Band Selection 4-3 [47]
 Number of Band Memories 4-3 [47]
 Beat Canceler 6-9 [95]
 Beep Volume Selection 16-2 [160]

- C -

Carrier Level Adjustment 5-8 [64]
 Cleaning 18-1 [181]
 Clock Date/Time Configuration .. 14-1 [147]
 Local Clock Date/Time/Zone .. 14-1 [147]
 Auxiliary Clock
 Zone/Identifier 14-2 [148]
 Date Display Format 14-2 [148]
 Clock Display Selection 14-2 [148]
 Clock Correction Using NTP
 (Network Time Protocol) 14-2 [148]
 Auto Correction Configuration
 Screen 14-2 [148]
 Configuring the NTP Server
 Address 14-3 [149]
 Turning ON/OFF Auto Clock
 Correction 14-3 [149]
 Manual Date and Time
 Correction 14-3 [149]
 Communication Log 5-27 [83]
 Selecting a Log File Format . 5-27 [83]
 Displaying a Time Stamp 5-28 [84]
 Editing a Log File 5-28 [84]
 Configuration A/B Switching 3-2 [34]
 Connector Pin Descriptions 1-6 [18]
 Crossband Repeater Connection
 and Operation 16-16 [174]
 CTCSS Mute Selection 16-8 [166]
 CW Mode Operation 5-8 [64]
 Break-in ON/OFF, Delay Time .. 5-8 [64]
 CW Sidetone Pitch Frequency .. 5-9 [65]
 CW Sidetone Volume 5-9 [65]
 CW BFO Sideband 5-9 [65]
 CW Rise Time 5-9 [65]
 CW Auto Tune 5-9 [65]
 CW Auto Xmit from SSB Mode ... 5-9 [65]
 CW to SSB Mode Frequency Shift 5-9 [65]
 CW Encoding/Decoding 5-10 [66]
 CW Communication Screen 5-10 [66]
 CW Decode Threshold Level ... 5-11 [67]
 CW Decode Filter 5-11 [67]
 CW Transmit via USB Keyboard 5-11 [67]

CW Message Memory Encoding .. 5-12 [68]
 CW Paddle Operation on
 Communication Screen 5-12 [68]
 CW Communication Logs 5-27 [83]
 CW Message Memory 5-14 [70]
 Switching the Method of
 Registering CW Messages .. 5-14 [70]
 Registering CW Messages via
 Text Input 5-14 [70]
 Registering CW Messages via
 Paddle Operation 5-15 [71]
 Contest Number 5-15 [71]
 Playing/Transmitting CW
 Messages 5-16 [72]
 Interrupt Keying 5-17 [73]
 Deleting a CW Message 5-17 [73]

- D -

Dimmer 4-2 [46]
 Brightness Level 4-2 [46]
 Dimmer Level 4-2 [46]
 Display Color Adjustment 17-3 [179]
 Drive Output (DRV) 4-11 [55]
 Drive Output ON/OFF 4-11 [55]
 Drive Output Level 4-11 [55]
 DSP Monitor 6-9 [95]
 Assigning DSP Monitor to
 PF Key 6-9 [95]
 Expanding Passband Width Using
 DSP Monitor 6-9 [95]

- E -

Emergency Call (K Type Only) .. 16-16 [174]
 External Device Control 16-12 [170]
 TX Inhibit When Squelch Open 16-12 [170]
 Reversing the PKS Polarity . 16-12 [170]
 USB Keying 16-12 [170]
 Decoded Character Output ... 16-12 [170]

- F -

Firmware Update 17-1 [177]
 Firmware Version Check 17-1 [177]
 FM Mode 5-28 [84]
 Microphone Gain 5-28 [84]
 Narrow FM Mode 5-29 [85]
 FM Repeater Operation 5-29 [85]
 Configuring Tone Signal 5-29 [85]
 CTCSS Operation 5-30 [86]
 Cross Tone 5-30 [86]

Frequency Adjustment 4-5 [49]
 Tuning Control 4-5 [49]
 Steps/Revolution 4-5 [49]
 Fast Forward Rate 4-5 [49]
 Fast Forward Sensitivity .. 4-5 [49]
 Fine Tuning 4-5 [49]
 Direct Input using Keypad 4-6 [50]
 MULTI/CH Control 4-6 [50]
 Rounding the Frequency 4-6 [50]
 SSB Step Size 4-6 [50]
 CW/FSK/PSK Step Size 4-6 [50]
 FM Step Size 4-6 [50]
 AM Step Size 4-6 [50]
 AM Broadcast 9 kHz Steps ...4-6 [50]
 MHz Key Steps ON/OFF 4-6 [50]
 MHz Key Step Size 4-6 [50]
 Microphone UP/DWN Tuning 4-5 [49]
 Frequency Input History 4-7 [51]
 Frequency Lock 4-7 [51]
 Lock Behavior 4-7 [51]
 Front Panel 2-1 [21]
 Key Behavior 2-1 [21]
 Key Long-press Duration 16-2 [160]
 Function Key Behavior 2-4 [24]
 Control Knob Behavior 2-5 [25]
 LED Behavior 2-6 [26]
 Connectors & Jacks 2-6 [26]
 Front Panel Accessory Connection 1-2 [14]
 Fuse Replacement 17-4 [180]
 Replacing External Antenna
 Tuner Fuse 17-4 [180]
 Replacing DC Power Cable Fuse 17-4 [180]

- G -

Ground Connection 1-1 [13]

- I -

Installation 1-1 [13]
 Internal Beats 18-12 [192]

- K -

Keyer (built in) 5-13 [69]
 PADDLE Jack Behavior 5-13 [69]
 KEY Jack Behavior 5-13 [69]
 Keyer Operation Mode 5-13 [69]
 Reversing Dot and Dash 5-13 [69]
 Mic Paddle Mode 5-13 [69]
 Keying Speed Adjustment 5-13 [69]
 Weighting Adjustment 5-14 [70]
 Weight Ratio Reverse 5-14 [70]

- L -

Lightning Arrestor Installation . 1-1 [13]
 Linear Amplifier Control 16-13 [171]
 Connection 16-13 [171]
 Linear Amplifier
 Menu Screen 16-14 [172]
 Turning Amplifier ON/OFF ... 16-14 [172]
 Keying Logic State 16-14 [172]
 Turning Amplifier
 TX Delay ON/OFF 16-14 [172]
 Amplifier TX Delay Time 16-14 [172]
 Amplifier Relay Control 16-14 [172]
 External ALC Voltage 16-14 [172]

- M -

Menu Operation 3-1 [33]
 Menu Call Up 3-1 [33]
 Sub-Menu Call Up 3-1 [33]
 Common Menu Screen Operations 3-2 [34]
 Exiting the Menu 3-2 [34]
 Menu Items
 Menu Group 0 -
 Basic Configuration 3-3 [35]
 Menu Group 1 -
 Audio Performance 3-4 [36]
 Menu Group 2 -
 Decoding & Encoding 3-4 [36]
 Menu Group 3 -
 Controls Configurations ... 3-5 [37]
 Menu Group 4 -
 Memory Channels & Scan 3-5 [37]
 Menu Group 5 -
 CW Configurations 3-5 [37]
 Menu Group 6 -
 TX/RX Filters & Misc. 3-6 [38]
 Menu Group 7 -
 Rear Connectors 3-7 [39]
 Menu Group 8 -
 Bandscope 3-7 [39]
 Menu Group 9 -
 USB Keyboard 3-7 [39]
 (Sub-)Menu Items
 Advanced Menu 3-8 [40]
 Reset Menu 3-8 [40]
 Linear Amplifier Menu 3-9 [41]
 Dimmer Menu 3-9 [41]
 USB/File Management Menu 3-9 [41]
 Clock Menu 3-10 [42]
 LAN Menu 3-10 [42]
 Timer Menu 3-11 [43]
 Auto Mode Menu 3-11 [43]
 KNS Menu 3-12 [44]
 Frequency Marker Menu 3-12 [44]

Memory Channels 9-1 [113]
 Memory Channel List Display
 (turn off Bandscope) 9-1 [113]
 Memory Channel Frequency and
 Mode Registration 9-2 [114]
 Memory Channel Direct
 Frequency Entry 9-2 [114]
 Memory Channel Mode Operation 9-2 [114]
 Memory Channel Number Direct
 Entry Using Keypad 9-2 [114]
 Temporary Frequency and Mode
 Changes 9-3 [115]
 Memory Channel Copy to VFO or
 Another Memory Channel 9-3 [115]
 Naming Memory Channels 9-4 [116]
 Erasing Memory Channels 9-4 [116]
 Meter 4-9 [53]
 Meter Type via the Menu 4-9 [53]
 Meter Type via Touchscreen ... 4-9 [53]
 Analog Meter Response 4-10 [54]
 Peak Hold ON/OFF 4-10 [54]
 S Meter Scale 4-10 [54]
 FM Mode S-meter Sensitivity . 4-10 [54]
 TX Meter Selection 4-9 [53]
 TX Meter (Digital) 4-10 [54]
 Meter (External – Rear Panel) .. 16-6 [164]
 Microphones (Optional) 2-8 [28]
 Microphone Gain Adjustment 4-8 [52]
 Mode Selection 4-4 [48]
 Monitor (External – Rear Panel) 16-7 [165]

- N -

Network/KNS Operation 15-1 [153]
 LAN Connection 15-1 [153]
 IP Address Configuration . 15-1 [153]
 View MAC Address 15-2 [154]
 KNS Operation 15-2 [154]
 LAN Connection Settings .. 15-3 [155]
 Administrator Settings ... 15-3 [155]
 User Registration 15-5 [157]
 Built-in VoIP 15-4 [156]
 Mute Transceiver Speaker . 15-4 [156]
 Remote User Operation 15-6 [158]
 KNS Welcome Message 15-6 [158]
 Session Time Limit 15-6 [158]
 Communications Log 15-5 [157]
 Noise Blanker 1 and 2 6-6 [92]
 Noise Blanker ON/OFF 6-6 [92]
 Adjusting the NB1 Level 6-6 [92]

NB2 Type A or B 6-7 [93]
 NB2 Effect Level (Type A) or
 NB2 Pulse Sensitivity Level
 (Type B) 6-7 [93]
 NB2 Blanking Duration
 (Type B Only) 6-7 [93]
 NB2 Attenuation Level
 (Type B Only) 6-7 [93]
 Noise Reduction NR1 and NR26-8 [94]
 Noise Reduction ON/OFF 6-8 [94]
 NR1 Effect Level 6-9 [95]
 NR2 Correlation Time 6-9 [95]
 Notch Filter 6-8 [94]
 Notch Filter ON/OFF 6-8 [94]
 Notch Filter Bandwidth 6-8 [94]

- O -

Optional Equipment & Software .. 19-1 [193]
 Installing the YG-82CN-1
 Roofing Filter 19-1 [193]

- P -

Packet Cluster Tuning 16-11 [169]
 Connection 16-11 [169]
 Receiving Data 16-11 [169]
 PC Connection 1-4 [16]
 PC Control 16-5 [163]
 Rear Panel COM/USB Baud Rate 16-5 [163]
 PF Keys (Programmable Function
 Keys) 16-2 [160]
 Assigning Functions to Front
 Panel PF Keys 16-2 [160]
 Assigning Functions to
 Microphone PF Keys 16-2 [160]
 Assigning Functions to KEYPAD
 Jack PF Keys 16-3 [161]
 List of Assignable PF
 Functions 16-3 [161]
 Power ON/OFF 4-1 [45]
 Power OFF Current 4-1 [45]
 Power-on Message Setup 16-1 [159]
 Power Output Adjustment 4-8 [52]
 Fine Adjustment 4-8 [52]
 Power Output Limiter 4-9 [53]
 Power Limiter ON/OFF 4-9 [53]
 Power Limiter Setup 4-9 [53]
 Power Supply Connection 1-1 [13]
 Preamplicifier Selection..... 5-6 [62]

PSK Operation 5-22 [78]
 PSK Communication Screen 5-22 [78]
 PSK Decode Threshold Level .. 5-23 [79]
 FFT Scope/Vectorscope Display
 Setting 5-24 [80]
 AFC (Automatic Frequency
 Control) 5-24 [80]
 Switching between BPSK and
 QPSK 5-24 [80]
 Switching between PSK31 and
 PSK63 5-25 [81]
 Transmitting Character Strings
 from USB Keyboard 5-25 [81]
 PSK Communication Logs 5-27 [83]
 PSK Message Memory 5-26 [82]
 Registering Messages 5-26 [82]
 Configuring Auto TX/RX 5-26 [82]
 Transmitting Character Strings from
 the PSK Message Memory ... 5-27 [83]
 Settings Related to PSK 5-27 [83]

- Q -

Quick Memory Channels 9-5 [117]
 Registering a Quick Memory
 Channel 9-5 [117]
 Calling up a Quick Memory
 Channel 9-5 [117]
 Number of Quick Memory
 Channels 9-5 [117]
 Erasing Quick Memory Channel . 9-5 [117]
 Quick Memory Transfer to VF0 . 9-6 [118]

- R -

Rear Panel Accessory Connection . 1-3 [15]
 Rear Panel Connectors & Jacks ... 2-7 [27]
 Reference Frequency Selection .. 16-8 [166]
 Reference Frequency (Internal)
 Calibration 17-2 [178]
 Reset Options 17-1 [177]
 RIT (RX Incremental Tuning) 5-7 [63]
 RIT Shift 5-7 [63]
 RF Gain Adjustment 4-2 [46]
 RTTY Operation 5-17 [73]
 RTTY Communication Screen ... 5-17 [73]
 RTTY Decode Threshold Level . 5-18 [74]
 FFT/X-Y Scope Display Setup . 5-18 [74]
 Transmitting Characters Using
 USB Keyboard 5-19 [75]
 RTTY Communication Logs 5-27 [83]
 RTTY Message Memory 5-20 [76]
 Registering RTTY Messages ... 5-20 [76]
 Configuring Auto TX/RX 5-20 [76]

Transmitting Character Strings
 from RTTY Message Memory . 5-21 [77]
 Settings Related to RTTY
 Encode/Decode 5-21 [77]
 RTTY Parameters 5-21 [77]
 Configuring Mark Frequency .. 5-21 [77]
 Configuring RTTY Shift Width 5-21 [77]
 Frequency Reverse in
 RTTY Mode 5-22 [78]
 RTTY (FSK) Using an External
 Device 5-22 [78]
 Connecting to a PC (using
 the USB port) 5-22 [78]
 Connecting other external devices
 (using ACC 2 connector) .. 5-22 [78]
 RTTY (FSK) Keying Polarity .. 5-22 [78]
 Audio Peak Filter 5-22 [78]
 RX Antenna 4-10 [54]
 RX Equalizer 5-4 [60]
 RX Equalizer ON/OFF 5-4 [60]
 RX Equalizer Type Selection .. 5-4 [60]
 Adjusting Equalizer
 Characteristics 5-4 [60]
 Copying Equalizer Data 5-5 [61]
 Saving Equalizer Data 5-5 [61]
 Reading Equalizer Data 5-5 [61]
 RX Filter A,B,C Selection 6-1 [87]
 RX Filter Scope 6-1 [87]
 RX Filter Setup 6-2 [88]
 Roofing Filter Selection 6-2 [88]
 IF Filter Shape Selection 6-2 [88]
 AF Filter Type Selection 6-2 [88]
 HI/SHIFT and LO/WIDTH Controls
 (SSB/SSB-DATA only) 6-3 [89]
 Cutoff HI/LO Frequencies
 (SSB, AM, FM only) 6-3 [89]
 Passband Width and Shift
 (CW or SSB-DATA only) 6-4 [90]
 HI/SHIFT and LO/WIDTH Preset . 6-5 [91]
 RX Monitor 5-6 [62]

- S -

Scan Functions 10-1 [119]
 Program Scan 10-1 [119]
 Program Scan Memory Channel
 P0-P9 Frequency Setup .. 9-4 [116]
 Program Scan (P0-P9)/VF0 Scan
 Configuration 10-1 [119]
 Starting Program Scan or
 VF0 Scan 10-1 [119]
 Scan Speed Selection 10-2 [120]
 Scan Hold ON/OFF 10-3 [121]

Program Slow Scan 10-2 [120]
 Program Slow Scan ON/OFF . 10-2 [120]
 Program Slow Scan Frequency
 Points 10-2 [120]
 Program Slow Scan Segment
 Width 10-3 [121]
 Memory Scan 10-3 [121]
 All-channel Scan and
 Group Scan Setup 10-3 [121]
 Performing Memory Scan ... 10-3 [121]
 Memory Channel Lockout ... 10-4 [122]
 Quick Memory Scan 10-4 [122]
 Conditions for Resuming Scan .10-4 [122]
 Screen Area Descriptions 2-9 [29]
 Screen Display Settings 4-1 [45]
 Background Color 4-1 [45]
 Function Key Display 4-1 [45]
 Frequency Display Font 4-1 [45]
 Screen Saver Configuration 16-1 [159]
 Screen Shot Capture 16-6 [164]
 Service Preparation 18-1 [181]
 Sky Command System II 16-17 [175]
 Connection Diagram 16-17 [175]
 Starting Operation 16-18 [176]
 Specifications 19-2 [194]
 Speech Processor 8-4 [108]
 Speech Processor ON/OFF 8-4 [108]
 Speech Processor Input Level . 8-4 [108]
 Speech Processor Output Level 8-4 [108]
 Speech Processor Effect 8-4 [108]
 Split Operation 5-1 [57]
 Delta F Display 5-1 [57]
 Delta F Direct Input 5-1 [57]
 Tuning Search for TX Frequency 5-1 [57]
 Split frequency via RIT/XIT .. 5-1 [57]
 Band Direct Key when Split ... 5-2 [58]
 TF-SET (Set TX Frequency) 5-2 [58]
 Split Frequency Transfer with
 Another Transceiver 16-9 [167]
 Transceiver Connections 16-9 [167]
 Split Transfer A 16-9 [167]
 Split Transfer B 16-10 [168]
 SQL Control Configuration 16-8 [166]
 PSQ Logic State Selection ... 16-8 [166]
 PSQ Output Conditions 16-8 [166]
 Switching the COM Connector
 for PSQ/PKS Operation 16-8 [166]
 Squelch Level Adjustment 4-2 [46]
 SWL (BCL) Mode 5-6 [62]
 SWL Band Switching (VFO Mode) 5-6 [62]

- T -

Timer Functions 14-4 [150]
 Configuring the Program Timer 14-4 [150]
 Pausing Program Timer 14-6 [152]
 Configuring the Sleep Timer . 14-6 [152]
 Pausing the Sleep Timer 14-6 [152]
 Touchscreen Adjustment 17-3 [179]
 Transverter/Exciter Operation . 16-15 [173]
 Transverter Connection 16-15 [173]
 TX Power Down with Transverter
 Enabled 16-15 [173]
 Configuring Transverter
 Operating Frequency 16-15 [173]
 Displaying Transverter
 Operating Frequency 16-15 [173]
 Troubleshooting 18-1 [181]
 Problems Related to Reception
 and Transmission 18-2 [182]
 Problems Related to Data
 Communication, PC
 and Network 18-5 [185]
 Problems Related to Recording
 and Playback 18-8 [188]
 Error Messages 18-9 [189]
 Warning Messages 18-11 [191]
 Tuning Control Fast Forward Rate 4-5 [49]
 Fast Forward Sensitivity 4-5 [49]
 Tuning Control Steps/Rev 4-5 [49]
 Tuning Control Torque 1-2 [14]
 TX Audio Input Path 8-1 [105]
 TX in Data Mode 5-7 [63]
 TX via PTT Switch, SS Terminal
 and SEND 5-7 [63]
 TX via DATA PTT or DATA SEND . 5-7 [63]
 TX Equalizer 8-5 [109]
 TX Equalizer ON/OFF 8-5 [109]
 TX Equalizer Frequency
 Characteristic Selection .. 8-6 [110]
 TX Equalizer Adjustment 8-6 [110]
 Copying the TX Equalizer
 Settings 8-6 [110]
 Saving the TX Equalizer
 Settings 8-7 [111]
 Reading the TX Equalizer
 Settings 8-7 [111]
 TX Filter 8-5 [109]
 TX Filter Bandwidth 8-5 [109]
 TX Filter Scope 8-5 [109]

TX ID Beep 8-8 [112]
 TX Inhibit 16-11 [169]
 TX Monitor 8-3 [107]
 TX Timeout Timer (TOT) 8-8 [112]
 TX Tuning Output Power 8-8 [112]

- U -

USB/File Management 11-1 [123]
 Managing Different File Types 11-1 [123]
 USB/File Management Menu ... 11-2 [124]
 File Destination Selection 11-2 [124]
 Saving Settings Data 11-2 [124]
 Reading Settings Data 11-3 [125]
 Changing Built-in Memory
 File Names 11-4 [126]
 Deleting Built-in Memory
 Files 11-5 [127]
 Copying Files to a PC 11-4 [126]
 Formatting USB Flash Drive 11-5 [127]
 Copying Files to a USB
 Flash Drive 11-5 [127]
 Saving Screen Saver Images 16-1 [159]
 Safely Removing the USB
 Flash Drive 11-6 [128]
 USB Keyboard Setup 16-5 [163]
 USB Keyboard Language
 Selection 16-5 [163]
 Key Repeat Delay Time
 Selection 16-5 [163]
 Key Repeat Speed Selection .. 16-5 [163]
 USB Keyboard Message
 Transmission 16-5 [163]

- V -

VFO A/B Selection 4-3 [47]
 Virtual COM Port 1-5 [17]
 Voice Guidance 13-1 [135]
 Adjusting the Voice Guidance
 Volume 13-1 [135]
 Adjusting the Voice Guidance
 Speed 13-1 [135]
 Voice Guidance Language 13-1 [135]
 Auto Voice Guidance 13-1 [135]
 Voice 1 13-2 [136]
 Voice 2 13-12 [146]
 Voice 3 13-12 [146]
 Voice Message Recording 12-1 [129]
 Recording a Voice Message ... 12-1 [129]
 Naming a Voice Message 12-2 [130]
 Deleting a Voice Message 12-3 [131]

Voice Message Playback 12-2 [130]
 Adjusting the Playback Volume 12-2 [130]
 Sending a Voice Message 12-3 [131]
 Repeat Transmission Time
 Interval 12-3 [131]
 Voice Communication Recording .. 12-3 [131]
 Manual Recording 12-3 [131]
 Full-time Recording 12-4 [132]
 Timer Recording 12-3 [131]
 Recording with Squelch 12-4 [132]
 Renaming an Audio File 12-6 [134]
 Deleting an Audio File 12-6 [134]
 Voice Communication Playback ... 12-4 [132]
 Quick Playback 12-4 [132]
 Audio Recording File Screen . 12-4 [132]
 Adjusting the Playback Volume 12-4 [132]
 Playing Back an Audio File .. 12-5 [133]
 VOX (Voice-Operated Transmit) ... 8-1 [105]
 VOX ON/OFF 8-1 [105]
 Data VOX Audio Selection 8-2 [106]
 VOX Gain 8-2 [106]
 Anti VOX Gain 8-2 [106]
 VOX Delay Time 8-3 [107]
 VOX Voice Delay 8-3 [107]

- X -

XIT (TX Incremental Tuning) 5-7 [63]
 XIT Shift 5-7 [63]

Compiled by WA1UJU